Vista Roll Screen April 7, 2005

Resetting the spring

1) Lay the Screen Housing on a flat surface. Holding the Side Bar, slowly uncoil the mesh until the Mesh Cylinder is visible.

2) Making certain that the Mesh is straight; begin by removing two small screws from the top of the Housing Assembly. Pull the Housing Assembly out of the Screen Housing only enough so that it can rotate freely but still be in contact with the Spring Assembly in the Mesh Cylinder. Charge the spring by rotating the entire Housing Assembly 33 times clockwise. Hold the Assembly firmly during the winding phase as it will recoil rapidly if released. Do not allow the Mesh Cylinder to turn during the winding phase as this will limit access to the Locking Tab. Once the spring is charged, lift the Locking Tab on the Mesh Cylinder, fully insert the Housing Assembly into the Screen Housing, and fasten firmly with the two screws into the top of the unit.

3) While holding the side bar, depress the Locking Tab, and allow the Screen Mesh to retract slowly into the Screen Housing. The Screen Housing in now ready for installation.