Vista Plus Screen

<When the operation is not smooth...>

Make sure if there is any gap between the Sliding Bar Bottom Cap and the Sliding Bar. If the gap is seen, push down the Sliding Bar to the bottom so that the gap disappears. In the case there is some gap, the Retracting Mesh Guide can be stuck in the inside of the Sliding Bar Bottom Cap.



Push down the Sliding bar to the bottom so that the gap disappears.